



## Steering Wheel Remote Control Functions



Button	Radio Mode (analogue/digital)	All Other Sources (except AUX)	Incoming/Active Call
a	Seek Up	Track up	n/a
b	Seek Down	Track down	n/a
c	Mute	Mute	n/a
d	Source	Source	n/a
e	Volume +	Volume +	Volume +
f	Volume -	Volume -	Volume -
g	n/a	n/a	OFF Hook
h	n/a	n/a	On Hook/Reject